

Installation Instructions

180 DEGREE HINGE KIT

Tel: 01782 339348 Fax: 01782 339349

sales@centrewire.com

www.centrewire.com

Mossfield Road, Adderley Green, Longton, Stoke-on-Trent, ST3 5BW



DESIGNED FOR A 175 X 175MM TIMBER POST

Before installation of the hinge set please ensure that the package contains all the items shown in the photograph (Left).

1 x 550mm Top Strap Band
1 x Double rocker Hinge Plate
1 x Bottom Bracket c/w 2 welded half pins
1 x Superhook to Bolt c/w antiturn hook
4 x M10 x 100 Coach Bolts c/w nut
2 x M10 x 100 Coach screws



If you need any further advice/guidance regarding the installations of any of our products please contact the office.

1. Offer up top 600mm Top band to top rail of gate and mark position of the three boltholes on each side.
2. Drill approx halfway through the top rail on both sides and holes should meet in the middle.
3. Feed the Coach bolts through and tighten.
4. Repeat the above three steps to fit the lower Double Rocker Hinge Plate.
5. Fit the Easy Latch® to gate assembly if purchased referring to separate instructions issued with the Easy Latch®.
6. Decide where the gate should hang on the post and mark the position of the top bolt. Drill the gatepost through for the top bolt and also the short hole required for the antiturn bar. Fit Superhook to Gatepost.
7. Hang the gate on the Superhook to Bolt, supporting the underside of gate until the bottom hinge is fitted.
8. Attach the bottom hinge to the gatepost, pins facing down. Remember to ensure a 5-10mm gap between the profiled lower double strap and the plate with double pins. This allows the gate to rise on the hinges when the gate is opened.
9. Cut off any excess thread on the Coach Bolts and remove any other rough edges



We strongly advise the use of personal safety equipment where appropriate: gloves, glasses boots etc.

 Centrewire®