

# Installation Instructions

## ASTON ONE WAY PEDESTRIAN GATE

Tel: 01782 339348 Fax: 01782 339349

sales@centrewire.com

www.centrewire.com

Mossfield Road, Adderley Green, Longton, Stoke-on-Trent, ST3 5BW



### Kit comprises of

- 2 x 2.4m Gate Posts
- 1 x Gate Leaf - 1.2m
- 1 x Easy Latch Kit - 1 Way
- 1 x 90 degree hinge kit

Installed Height - 1.2m  
Width post to post - overall 1.7m

Additional Options - trombone handle is supplied as standard, this can be replaced with straight or stockproof handle (additional charge for the stockproof handle)

We strongly advise the use of personal safety equipment where appropriate: gloves, glasses boots etc.

## PREPARE THE GATE

Attach the 24" hinge (with offset eyes on the gate post side) to the gate as follows: Mark the position of the 3 holes on each side.

Drill approximately halfway through the top rail from each side and hope to meet in the middle.

Feed the coach bolts through and tighten up.

Drill the hanging stile on the gate to take the adjustable bottom hinge which fits between the bottom 2 rails.

## PREPARE THE GATEPOST

Decide where the gate should hang on the post and mark the position of the square plates.

If one of the hooks is to be reversed for added security place the plates to allow approximately 5mm for the gate to rise between its open and closed positions.

Attach the plates to the gate post with two coach screws only.

Fixing of the bottom (adjustable) plate requires a short hole to be drilled in the post to take the threaded screw.



If you need any further advice/guidance regarding the installations of any of our products please contact the office.

## INSTALL THE GATEPOSTS AND GATES

Dig the hole for the hanging post, insert it and ram the bottom of hole with stones or rubble. Check that the post remains upright.

Backfill the hole with the most solid material available.

Attach the gate, which should fall naturally to its closed position.

Check that the gate is level and upright in the closed position and adjust the position of the square plates if necessary.

Insert the remaining coach screws.

Install the slam post so that the gate overlaps it by approximately 50mm.

Fit the EASY LATCH kit

## COMPLETION

Re-check that the gate and posts are upright and level and tighten all nuts.

Cut away any excess thread.

Check that the gate is completely free of all sharp edges.

**N.B. EXERTING STRAIN AGAINST ANY PART OF THE GATE ASSEMBLY WILL PREVENT ITS CORRECT OPERATION**

 Centrewire®