

Installation Instructions

DENSTONE ONE WAY PEDESTRIAN GATE

Tel: 01782 339348 Fax: 01782 339349

sales@centrewire.com

www.centrewire.com

Mossfield Road, Adderley Green, Longton, Stoke-on-Trent, ST3 5BW



Kit comprises of

- 1 x H Frame
- 1 x Gate Leaf - 1.2m
- 1 x Easy Latch Kit - 1 Way
- 1 x 180 degree hinge kit
- 1 x Gate stop

Installed Height - 1.2m

Width post to post - overall 1500mm

Additional Options - trombone handle is supplied as standard , this can be replaced with straight or stockproof handle (additional charge for the stockproof handle)

We strongly advise the use of personal safety equipment where appropriate: gloves, glasses boots etc.

These gates are normally transported as one complete unit. For ease of handling and installation it is possible to detach the gate from its frame.

INSTALLING THE GATE

Two Holes and a shallow trench are required. The trench should be deep enough for the bottom of the gate to be approximately 75mm above ground level. The cross bar must be level if the ground is uneven. It is possible to increase the height of the gate to match the adjoining fence but remember that if the cross bar is too close to ground level it may become a problem in wet weather on a busy path.

Check level and vertical alignment of the frame before filling the holes and trench with rubble and/or concrete.

COMPLETION

Re-check that the gate and posts are upright and level and tighten all nuts.

Check that the posts are completely free of all sharp edges. Remove any rough patches of zinc with a file or sandpaper.

N.B. EXERTING STRAIN AGAINST ANY PART OF THE GATE ASSEMBLY WILL PREVENT ITS CORRECT OPERATION



If you need any further advice/guidance regarding the installations of any of our products please contact the office.

Centrewire®