

Installation Instructions

DOGWAY LATCH AND BRACKETS

Tel: 01782 339348 Fax: 01782 339349

sales@centrewire.com

www.centrewire.com

Mossfield Road, Adderley Green, Longton, Stoke-on-Trent, ST3 5BW



Kit comprises of

1 x Dogway Latch

2 x Brackets

1 x Stop and Bolts

Installed height - upto 1.2m

Width of latch - 175mm

IMPORTANT

These are designed to fit either onto posts and two rails of existing stiles or fences (DOGWAY LATCH & BRACKETS)

We strongly advise the use of personal safety equipment where appropriate: gloves, glasses boots etc.

ASSEMBLY

Normally these are attached to existing stiles or adjoining fences.

Create the gap, by using an existing post and inserting an extra upright. Normally an upturned rail will suffice. The gap i.e. the distance between the inside of the post and upright must not exceed 300mm.

Attached the brackets to the two top rails

Cut the lower rails

The DOGWAY LATCH rests on the top rail.

Check the position for the stop: it should be bolted to the vertical slats on the rails side. Cut and drill as necessary, the stop should be 50mm from ground level when the latch is closed(i.e. down)

Tighten the screws and nuts.

Check that the DOGWAY LATCH lifts and closes freely and remove any sharp edges from the structure.



If you need any further advice/guidance regarding the installations of any of our products please contact the office.

 Centrewire[®]