

Installation Instructions

STAND A LONE DOGWAY

Tel: 01782 339348 Fax: 01782 339349

sales@centrewire.com

www.centrewire.com

Mossfield Road, Adderley Green, Longton, Stoke-on-Trent, ST3 5BW

IMPORTANT

These are designed to fit either onto posts and two rails of existing stiles or fences (DOGWAY LATCH & BRACKETS) or as a seperated assembly (STAND A LONE DOGWAY)

Please check that you have all the required components on site to complete the installation



Kit comprises of

- 1 x Dogway Latch
- 2 x Brackets
- 1 x Stop and Bolts
- 2 x 1.8m Posts
- 1 x 1.2m rail

Installed height - upto 1.2m

Width of latch - 175mm

We strongly advise the use of personal safety equipment where appropriate: gloves, glasses boots etc.

ASSEMBLY

This is designed to fit in a fenceline adjacent to a stile.

Cut 2 lengths of 350mm from the rail

Cut 2 x 50mm sections from the offcut to block off the bottom mortice of the two posts and nail

Assemble the two posts and two 450mm rails. Check that the posts are parallel and are not more than 300mm apart and nail the rails in the mortices.

Install the frame work so that the top rail matches the adjoining fence, and attach the brackets to the two top rails.

The DOGWAY LATCH rests on the top rail.

Check the position for the stop: it should be bolted to the vertical slats on the rails side. Cut and drill as necessary, the stop should be 50mm from ground level when the latch is closed (i.e.down)

Tighten the screws and nuts.

Check that the DOGWAY LATCH lifts and closes freely and remove any sharp edges from the structure.



If you need any further advice/guidance regarding the installations of any of our products please contact the office.

 Centrewire®